

CLASSIC WOODEN CANDLE BRIDGE

KINGFISHER
festive



PLEASE READ ALL INSTRUCTIONS AND SAFETY NOTES BEFORE USE. FAILURE TO FOLLOW ALL INSTRUCTIONS LISTED BELOW MAY RESULT IN DAMAGE. PLEASE SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

SAFETY INSTRUCTIONS

Carefully remove the light set from the packaging without stretching or damaging the lights.
Do not illuminate the light set whilst it is in the packaging. Risk of overheating.
This light set is not suitable for illuminating rooms on its own.
This light set is not a toy. Children should not play with this product. Keep out of reach of children.
This candle bridge is for indoor decoration use only. Do not use outdoors or in wet environment including uninsulated damp windows.
Inspect the product including its power cable and plug for any signs of damage. Do not use if damaged.
Choose a suitable location for your lights and make sure that the socket you decide to use is close enough to the area you wish to decorate and that the cable will reach the socket without becoming an obstacle or hazard.
Please ensure that the bulbs are not covered and have adequate airflow.
Do not operate the lights in wet, hot, damp or excessively humid conditions.
Do not connect this light set electrically to another product by cutting or joining sets together.
Failed bulbs should be removed and replaced immediately with a bulb of the same rated voltage and wattage.
Do not attempt to push in the "SCREW IN" bulbs.
Failed bulbs should be removed and replaced immediately with a bulb of the same rated voltage and wattage.
Do not expose to direct heat, flame or submerge in water.
Always unplug from the mains supply whilst installing, maintaining, removing or inserting any bulbs.
Disconnect the light set from the mains supply if you do not intend to use the product for long time.
Do not use the light if the insulation or cable is damaged. If the cable is damaged, the lights must be discarded.
Disconnect the plug from the mains supply when not in use. Do not leave switched on light set unattended.
Never touch the plug or the light set itself with wet hands.
CAUTION! Bulbs can become hot in use. Do not touch the bulbs. Allow to cool down before replacing.
Do not attach any other objects to the product.

IMPORTANT

This candle bridge can only be used as an indoor decoration and under no conditions should be used outdoors. Before using this candle bridge, make sure that all the bulbs are secure in their holders. This candle bridge has been designed so that under normal conditions, if a bulb fails, the remaining bulbs will continue to work provided the defective bulb is otherwise undamaged and is securely fitted. This candle bridge comes with "SCREW-IN" replaceable bulbs. Also, check the fuse inside the fitted BS plug if the lights fail to work.



EC SAFETY STANDARDS

This light set is constructed to meet the European Safety Standard
BS EN 60598-2-20
and complies with the European Low Voltage Directive 2014/35/EC.

	CLS7	
	5 013478 125552	
	BPL - NG8 4GP	B1801P/M
		BATCH NO.

OPERATION

CAUTION! The bulbs may become loose during transport. Before use, check that all the bulbs are seated correctly in their fittings.

1. Place the candle bridge in desired location. Ensure there are no flammable objects directly above the light set.
2. Check the bulbs sit correctly in their fittings.
3. Insert the mains plug into a suitable mains socket.
4. Switch the light set on using the ON/OFF switch located on the cable.
5. To switch the light set off, press the light switch to OFF position and remove the plug from mains socket.

CHANGING BULBS

DANGER! RISK OF ELECTRIC SHOCK! Remove the plug from mains socket before performing any cleaning or maintenance task on this light set.

CAUTION! RISK OF BURNS! Allow the light set to cool down completely before changing the bulbs.

1. Turn the faulty light bulb in clock-wise direction to remove it from the lamp holder.
2. Insert new bulb of the same specification in the light fitting.
3. Plug in and switch on the cable.

CLEANING AND STORAGE

CAUTION! RISK OF ELECTRIC SHOCK! Remove the plug from mains socket before performing any cleaning or maintenance task on this light set.

Never clean this light set with water or other liquids or immerse it in water. Use a dry, lint-free cloth to clean this product. Do not use any solvents, petrol or similar items to clean this device.

Store in dry and cool location, out of reach of children. We recommend keeping the original product packaging for storage of the item when not in use for long time.

REPLACING THE PLUG

This product is supplied with a plug which complies to BS 1363-1 standard and is fitted with a 3A fuse. If necessary to replace the plug please follow the following wiring instructions:

Blue wire - Neutral terminal; Brown wire - Live terminal.

No connection is to be made to the earth terminal of the plug. The plug must be fitted with 3 amp fuse.

The external flexible cable or cord of this light set cannot be replaced. If cable is damaged, the light set must be destroyed.

PRODUCT SPECIFICATION	
Model No.	CLS7
Rated Power	220-240V~50Hz, 21W
Bulb Rating	7 x 34V, 3W
Bulb Fitting Type	E10 - Screw-in
Cable Length	1.5m, BS 3 Pin plug with 3 amp fuse fitted.